


F.R.E.D.

T1 3/4 (5mm)
Superbright RED LED

#1539



Installation Instructions:

Locate a position to place the FRED pc board. You may want to make two slits to accommodate the LED leads without removing it. If you choose to extend the LED from the main board, it is important to connect the LED leads in the same polarity. Having them reversed will cause the LED to not illuminate and may burn out the LED.

Position the FRED, making sure the area is clean of grease for proper adhesion, peel tape covering and place in position.

Connect the input wires to either a 9 Volt battery or cut the battery snap end off and connect wires to the track pickup shoes (polarity of the wires is not important). Input power can be from DC, AC, or DCC and up to 20 volts. If utilizing a battery, an on/off switch (Item #524) may be used.

Be sure not to short the LED leads, or any other parts to any other metal part, this will damage the FRED.

DALLEE
ELECTRONICS, Inc.

246 W. Main St.
Leola, PA 17540
(717) 661-7041
www.dallee.com