


Automatic Reverse of Turning Loops using slip switches with direction memory utilizing the Trak-DTRL



This diagram is for any 2 rail operation, AC or DC track power!

Upon first initialization, make sure the trolley/train is running in the correct direction. Once established you should never reverse the DC track power supplied. Since the Trak-DTRL maintains polarity the trolley will always start in the correct direction from the previous operating session. Slip switches need to be set to follow the "direction of travel", otherwise the "Sense" section will need to be moved.