

# **BEACON**

**T1 ¾ (5mm)**  
Superbright RED LED

#1536



#### Installation Instructions:

Locate a position to place the BEACON pc board. If you choose to extend the LED from the main board, it is important to connect the LED leads in the same polarity. Having them reversed will cause the LED to not illuminate and may burn out the LED.

Position the BEACON, making sure the area is clean of grease for proper adhesion, peel tape covering and place in position.

Connect the input wires to either a 9 Volt battery or cut the battery snap end off and connect wires to the track pickup shoes (polarity of the wires is not important) or a fixed voltage source. Input power can be from DC, AC, or DCC and up to 20 volts. If utilizing a battery, an on/off switch (Item #524) may be used.

Be sure not to short the LED leads, or any other parts to any other metal part, this will damage the BEACON.

**DALLEE**  
**ELECTRONICS, Inc.**

246 W. Main St.  
Leola, PA 17540  
(717) 661-7041  
[www.dallee.com](http://www.dallee.com)